

HOME / PRODUCT CATEGORIES / BUTTON / LED TACTILE BUTTON BREAKOUT



# LED Tactile Button Breakout

● BOB-10467 ROHS ✓

DESCRIPTION DOCUMENTS

This simple breakout board makes it easy to use our LED tactile switches in a breadboard, or your next project.

{ }

**Note:** Populate the board according to the polarity of the LED on the switch. The markings for the switch are irrelevant and can be reversed.

LED Tactile Button Breakout Product Help and Resources

TUTORIALS

SKILLS NEEDED



Vernier Photogate JANUARY 7, 2014

Vernier Photogate Timer -- using the Serial Enabled LCD Kit.

COMMENTS 20 REVIEWS 0

## **Customer Comments**

Log in or register to post comments.

Member #826541 / about 2 years ago / 🖈 1

Hi I need an help, it is not clear to me how to connect the wires... I am using a x-OSC board (3.3 V), not arduino. I connect the A to voltage, C to pulldown (10k resistor) and then to GND. In this way the led is always on.... What I am doing wrong? And how/where I connect B1 and B2? Thanks in advance

#### M-Short / about 2 years ago / \*1

A and C are the anode and cathode of the LED. While a pulldown resistor is not needed for LEDs a current limiting resisitor is. Usually a 330 ohm resistor is used. which should limit the current to 5-20mA depending on the LED forward voltage and the VCC being used. With 10k, I'm guessing your LED is very dim if you can see it at all. If you want to control the LED from your microconroller you can connect either C or A to an output and when you pull that pin low or high respectively the LED should turn on. As for B1 and B2 those are the 2 sides of the button. Basically when the button is pressed the 2 pins are connected and power flows between them. The standard configuration for a button is to have the microcontroller input on one of the pins and GND on the other. That way when the button is pressed the microcontroller is pulled to ground. You will also want a pullup resistor on the pin connected to the microcontroller so that when the button is not pressed that pin is pulled up and not just floating. If you have any other questions feel free to contact our techsupport team.

Kevin-O / about 7 years ago / 🖈 3

I agree that it will work either way, but it's annoying that I followed the markings and had to spend time debugging it.

You really should make a note in the product listing until you fix the silkscreen.



Ah ok, the numbering isn't consistent with the anode and cathode labels. Follow the labeling for anode and cathode and you'll be fine.

charredgrass / about 5 years ago / ★ 2

Why do we need a breakout for a freaking button?

CMoyni24 / about a year ago / 🖈 1

The LED button is easier to use this way.

Member #475489 / about 4 years ago / ★ 2

so you can (easily) use it with a breadboard as shown in the last picture...

Member #160138 / about 7 years ago \* / 🖈 2

BEWARE ! Numbering nomenclature on the printed circuit board is incorrect!

#4 on the board should be #1, #2 on the board should be #3,

#3 on the board should be #2, #1 on the board should be #4,

OR ... you can look at it in another way: the numbering is correct but the cathode / anode markings on the board is reversed.

Either way ....

Check out the polarity of the diode on the LED switch and numbering before you place it on the board and solder it!!! Other than that, this is a nice convenient board to use. I recommend it.



The board will work either way-you just need to make sure that your power in is wired correctly.

```
tash / about 4 years ago / ★ 1
```

The markings on the board is correct. The eagle file is not matching the board. The tactile switch in this eagle file has incorrect LED pin markings. I grabbed part from this eagle file and used in a design and has few boards that is messed up, I have LEDs that are ON all the time as I was driving it along with 7-seg displays. The part in sparkfun eagle library (TACTILE-PTH-LED-12MM & EZ) are correct. Sparkfun, please update/remove eagle file in this page..

#### Toni\_K / about 4 years ago / ★1 and the

We are getting them updated, but keep in mind the files that are posted are the same circuit as the board. The difference is that the C/A headers are reversed, but the connections on the LED are also reversed. As I said, you can use the board either way, you just need to make sure you wire in power to the LED correctly.

Sean Ahrens / about 4 years ago / 🖈 1

hat resistor would I need on the LED terminal if the LED is powered by a 3.3v Lilypad on a 40mA Digital Out?

Beelzebot / about 5 years ago / ★ 1 G'day, would be nice if this board had provisions for a current limiting resistor :)

Member #333250 / about 5 years ago / 🖈 1

I cut the trace to the cathode and soldered on a 120 ohm 1206smd. It seems to work though pads would have made it easier. it would also be nice to have pads to jumper Gnd or Vcc to one side of the switch.

Kamiquasi / about 5 years ago / ★ 1

But then the board would be larger :)

It is my understanding that you wouldn't necessarily use this as a stand-alone board in a project (if it were, it would do well with a mounting hole, for one), but specifically for use on a typical breadboard. This makes sense, as the pins overlap in a breadboard's columns, but are too close together to fit across the DIP channels to separate them. If it's in a breadboard, adding resistors is usually not a problem :)

Member #169573 / about 7 years ago / 🖈 1

I can not download the file because it opens an eagle another page with several characters, someone can give me a download link?

elmartin76 / about 7 years ago / 🖈 1

Sorry for such a novice question, but I'm just starting in this world. :) How are you supposed to connect this to an Arduino? I suppose C goes to GND, A to 5V, but... B1 and B2? thanks

icyfyer / about 6 years ago / 🖈 2

Sparkfun stole my formatting...

icyfyer / about 6 years ago / ★ 2

A little late, but maybe you still need the info. If you are sourcing current to the LED from the Arduino: C - GND A - Arduino through current limiting resistor B1 - GND B2 - Arduino with pull-up resistor (10K connected to 5V)

Set ledPin to OUTPUT Set buttonPin to INPUT

digitalWrite(ledPin, HIGH); //turn on LED digitalWrite(ledPin, LOW); //turn off LED

B2 is the button output, also the input for the Arduino; pushing the button sends buttonPin LOW.

Pazu / about 7 years ago / 🖈 1

### Hi,

Are you able to include the dimensions of this breakout?



SUBSCRIBE TO NEWSLETTER

In 2003, CU student Nate Seidle blew a power supply in his dorm room and, in lieu of a way to order easy replacements, decided to start his own company. Since then, SparkFun has been committed to sustainably helping our world achieve electronics literacy from our headquarters in Boulder, Colorado.

No matter your vision, SparkFun's products and resources are designed to make the world of electronics more accessible. In addition to over 2,000 open source components and widgets, SparkFun offers curriculum, training and online tutorials designed to help demystify the wonderful world of embedded electronics. We're here to help you start something.

About Us About SparkFun SparkFun Education C Feeds Jobs Downloaded from Arrow.com. Help Customer Service Shipping Return Policy FAQ Chat With Us



Eor	which	dona	rtment?
FUL	WIIICH	uevai	unent:

What's on your mind?

0
(-eneral

Please include your email address if you'd like us to respond to a specific question.

email address

SUBMIT

## Programs

## Community

Become a Community Partner • Community Stories Custom Kit Requests Tell Us About Your Project Sell Your Widget on SparkFun Become a SparkFun Distributor Large Volume Sales Forum SparkFun IRC Channel Take the SparkFun Quiz SparkFun Kickstarter Projects Distributors

SparkFun Electronics ® / Niwot, Colorado / Customer Service / Site Map / Terms of Service / Privacy Policy

Questions? Feedback? powered by Olark live chat software