

# Instruction manual for Evaluation Board of TB67S101AFTG

May 16, 2016 Re v.1.0



### [Outline]

The TB67S101AFTG is a two-phase bipolar stepping motor driver using a PWM chopper. PHASE control system and BiCD process are adopted. Rating of 50V and 4.0A is realized.

This evaluation board mounts necessary components to evaluate the IC. Each excitation drive of full step, half step, and quarter step can be run with PWM constant current drive. Please sense low noise and low vibration of the stepping motor.

### [Note]

In using, please be careful about thermal condition sufficiently.

As for each control signal, please refer to the IC specification by accessing to the below URL.

http://toshiba.semicon-storage.com/info/lookup.jsp?pid=TB67S101AFTG&region=apc&lang=en Further, the application of this evaluation board is limited to the purpose of evaluating and learning the motor control. Please do not ship them to a market.




## **Connection to Evaluation board**

#### **Corresponding table**

#### (Silk name vs. Signal name)

(Note) Silk name and signal name on the board are different because the series products have the common board.


Silk name	Signal name
L_OUT	NC
38	NC
39	NC
VREFB	VREFB
42	VREFA
OSCM	OSCM
44	INA1
45	INA2
46	PHASEA
47	PHASEB
2	IN_B1
3	IN_B2
4	STANDBY





## Setting evaluation board 1

### **Setting motor current**




#### Setting motor current

out(max) = VREF(gain) x 
$$\frac{Vref(V)}{Rrs(\Omega)}$$

VREF(gain):Decay ratio of VREF: 1/5.0 (typ.)

#### RRS=0.22Ω


VREF of A-axis and B-axis are made common by short the jumper (JP\_VRF1) and the both voltages are possible to input from VREFA pin. And Vref can be generated from the internal regulator (VCC) by mounting the divider resistance to R\_VRF1 and R\_VRF2 and shortcircuiting JP\_VRF2.





## Setting evaluation board2


Setting chopping frequency of the constant current of the motor



Formula of setting chopping frequency

fOSCM = 1 / [0.56 x {C x (R1 + 500)}] fchop = fOSCM / 16


Recommended frequency range: fchop=40kHz to 150kHz 100kHz configuration Mounted parts are as follows; Capacitor (C=270pF), Resistance (R1=3.6k $\Omega$ )






## Setting evaluation board3

### **Setting motor operation**



#### [Enhanced figure of jumper part]



Jumper indicated above is adopted on this evaluation board to set operation of the TB67S101AFTG.

To select the function by the jumper, shortcircuit JP\_VCC or supply the voltage of high level by VDD pin.

In above, fixed level of the silk near the jumper is indicated inside the white frame. Please change the short position according to the configuration of the usage function. In case of inputting the signal externally, please remove the short pin.



### **Circuit of evaluation board**

