

GROUND-REFERENCE MODULES

| GROUND-REFERENCE MODULES | | | |
|--|--|--|---------------|
| Product | | Features | Accessory For |
| SE-GRM024 Ground Reference Module | G P CONTROL OF CONTROL | Connects the SE-601 relay to an ungrounded 24 Vdc bus. | SE-601 |
| SE-GRM048 Ground Reference Module | G Turning | Connects the SE-601 relay to an ungrounded 48 Vdc bus. | SE-601 |
| SE-GRM125 Ground Reference Module | G | Connects the SE-601 relay to an ungrounded 125 Vdc bus. | SE-601 |
| SE-GRM250 Ground Reference Module | Multilities of | Connects the SE-601 relay to an ungrounded 250 Vdc bus. | SE-601 |
| SE-GRM300 Ground Reference Module | • Est • • • • • • • • • • • • • • • • • • • | Connects the SE-601 relay to an ungrounded 300 Vdc bus. | SE-601 |
| SE-GRM400 Ground Reference Module | • Est • • • • • • • • • • • • • • • • • • • | Connects the SE-601 relay to an ungrounded 400 Vdc bus. | SE-601 |
| SE-GRM500 Ground Reference Module | S S S S S S S S S S S S S S S S S S S | Connects the SE-601 relay to an ungrounded 500 Vdc bus. | SE-601 |
| SE-GRM600 Ground Reference Module | STANTOO | Connects the SE-601 relay to an ungrounded 600 Vdc bus. | SE-601 |
| SE-GRM780 Ground Reference Module | | Connects the SE-601 relay to an ungrounded 780 Vdc bus. | SE-601 |
| SE-GRM1000 Ground Reference Module | | Connects the SE-601 relay to an ungrounded 1000 Vdc bus. | SE-601 |